

Problem determination and troubleshooting

How to perform problem determination actions on the water-cooling module

Lenovo

Troubleshooting overview

To determine the cause of problems with Neptune Liquid Cooling solutions, work through the following actions:

- Check the system status and the system event log on the XCC dashboard. Issues with water cooling modules might cause high temperatures in the processor, GPU, and other major components.
- Check the operating panel on the front of the system.
- Inspect the LEDs on the leakage detection sensor and the LED on the water-cooling module.
- For the DW612 or DW612S enclosures, check the drip sensor LED.
- Visually check if there is a coolant leak from the water-cooling module and manifold.
- For the ThinkSystem SD650, check the enclosure FDC messages.
- For the ThinkSystem SD650 V2, SD650 V3, and SD665 V3, check the enclosure SMM2 messages.
- Use IPMI commands to identify a coolant leak.

Note: For detailed error messages of water leakage problems, go to [Lenovo Docs](#).

Using XCC to identify a coolant leak

If the amber LED on the front operator panel is lit, check the XCC event log.

If an XCC event has an ID of **FQXSPUN0019M** and a message stating: **Sensor Liquid Leak has transitioned to critical from a less severe state**, it can be identified as a coolant leakage.

Event Log						
Audit Log Maintenance History Alert Recipients						
Customize Table Clear Logs Refresh Type: 🔴 🟡 🟢 All Event Sources All Dates 🔍						
Index	Severity	Source	Common ID	Message	Date	
0	🟢	System	FQXSPUN2019I	Sensor Ext Liquid Leak has transitioned to a less severe state from critical.	January 25, 2024 1:16:43 PM	
1	🔴	System	FQXSPUN0019M	Sensor Ext Liquid Leak has transitioned to critical from a less severe state.	January 25, 2024 1:13:22 PM	

Health Summary		Active System Events (2)	
🔴	Others	Sensor Ext Liquid Leak has transitioned to critical from a less severe state.	
		FQXSPUN0019M	FRU: January 25, 2024 2:21:16 PM
🟡	Others	Sensor RoT Attestation has transitioned from normal to warning state.	
		FQXSPUN0059J	FRU: 011B January 25, 2024 1:53:00 PM



Leakage detection sensor module

The leakage detection sensor module is used to detect coolant leakages in the system. When the module is installed in the hose holder, the leakage detection sensor LED should face up. A blinking green light indicates an abnormal status, while a solid green light indicates that no coolant leakage has been detected.

DWCM



L2AM




Leakage detection sensor LED

DW612 and DW612S drip sensor module

The DW612 drip sensor is used in both the DW612 and DW612S to monitor enclosure leaks. The sensor is designed to detect drips or leaks from the liquid-cooling system that could cause damage to the server or its components. Each enclosure has two drip sensors at the rear of the system.

Note: If a sensor detects moisture in its drip sensor catch basin, it activates a yellow LED that is visible through a hole located in the lower left leg of the lower EMC shield.



Using IPMI commands to identify a coolant leak

If the amber LED is lit on the front operator panel, IPMI commands can be used to check the system running status. IPMI commands with a `sel elsit` parameter can be used to check for a coolant leakage status.

```
zuody2@zuody2-07:~$ ipmitool -H 10.245.50.35 -U USERID -P Aa12345678 -I lanplus -C 17 sel elist
```

1	01/25/2024	13:40:30	Event Logging Disabled SEL Fullness	Log area reset/cleared	Asserted
2	01/25/2024	13:41:58	Cooling Device Ext Liquid Leak	Transition to Critical from less severe	Asserted
3	01/25/2024	13:42:01	Cooling Device Ext Liquid Leak	Transition to Critical from less severe	Deasserted

If there is a coolant leakage, the log indicated above will be displayed. The status of all sensors can be checked with the `sdr elist` parameter. (Click [HERE](#) for a picture.)



```
C:\ipmitool>ipmitool -I lanplus -H 192.168.70.125 -U USERID -P xccPASSWORD sdr elist
```


CPUs	0Ah	ok	37.3	
All CPUs	04h	ok	37.3	
One of CPUs	18h	ok	37.3	
CPU 1	F2h	ok	3.1	Presence detected
CPU 2	F3h	ok	3.2	Presence detected
CPU 1 UPILinkErr	F4h	ok	3.1	
CPU 2 UPILinkErr	F5h	ok	3.2	
Sys Boot Status	24h	ok	34.1	
Sys Utilization	DCh	ok	19.1	0 unspecified
CPU Utilization	D9h	ok	19.1	0 unspecified
Mem Utilization	DBh	ok	19.1	0 unspecified
IO Utilization	DAh	ok	19.1	0 unspecified
ME Status	F8h	ok	46.1	
Sys Power	A1h	ok	19.1	20 Watts
CPU Power	A3h	ns	19.2	No Reading
Mem Power	A4h	ns	19.3	No Reading
PSU Mismatch	FBh	ok	19.1	Transition to OK
PS Heavy Load	FCh	ok	19.1	State Deasserted
Power Resource	FDh	ok	19.1	
Power Supply 1	DDh	ok	10.1	Presence detected
PSU1 Failure	DEh	ok	10.1	Transition to OK
PSU1 PF Failure	DFh	ok	10.1	Transition to OK
PSU1 IN Failure	E0h	ok	10.1	Transition to OK
PSU1 AC In Pwr	A5h	ok	19.5	224 Watts

Resolving DWCM coolant leaks

If the LED on the leakage detection sensor module is blinking green or if XCC reports a leakage event, work through the following steps to resolve the problem:

- Save and back up data and server operations.
- Power off the server and remove the quick connect plugs from the manifolds.
- Slide out the server or remove it from the rack, and then remove the top cover.
- Check for coolant leaks around the outlet and inlet hoses, system board assembly, and under the cold plate covers.
- If coolant is found around the hoses and system board assembly, clean it up.
- If coolant is found under the cold plate covers, remove at least four DIMMs on each side to get access to the clips on the cold plate covers. (Click [HERE](#) to see a picture.)
- Replace the DWCM.
- As coolant might have dripped down on to the lower servers, check the top cover of the next server down. If you find coolant, work through these steps again.

Note: If there is a leak, the coolant tends to collect in leak-prone areas.




Resolving DWCM coolant leaks



If there is a coolant leak, remove the cold plate cover.

Note: Remove at least four DIMMs from each side to get access to the clips on the cold plate covers.



Resolving L2AM coolant leaks

If the LED on the leakage detection sensor module is blinking green or if XCC reports a leakage event, work through the following steps:

- Check for green coolant leakage around the radiator, coolant pipes, and processor cold plate.
- If green coolant is found, power off the server and remove the liquid to air module.
- Clean up the coolant from any components in the chassis, and then inspect the server for any signs of moisture in sockets or gaps.
- Replace the liquid to air module.

