

Power supply and fan troubleshooting


PSU and fan issues

Lenovo


Power supply diagnostics overview

To identify power supply issues, carry out the following actions:

- Physically look at the PSU indicator LEDs.
- Log in to Prism and go to **Hardware** → **Diagram** to check each server's power supply status.
- The `#ncc hardware_info show_hardware_info` command also shows the status of the PSU. (Click [HERE](#) to see the example output.)
- Go to the IMM/XCC interface.
- Use the host or CVM to run `ipmitool` commands. (Click [HERE](#) to see an example output.)



Physically check PSU LEDs



Use Prism to check the PSU




Power supply diagnostics overview

Output of #ncc hardware info show hardware info actions:

System Power Supply

Location	PS
Manufacturer	ARTE
Max power capacity	0.0 W
Product part number	SP57A03100
Serial number	P4LD83Y019F
Status	Present, OK
+-----	
Location	PS
Manufacturer	ARTE
Max power capacity	0.0 W
Product part number	SP57A03100
Serial number	P4LD83Y018J
Status	Present, OK
+-----	



Physically check PSU LEDs



Use Prism to check the PSU



Power supply diagnostics overview

To identify power supply issues, carry out the following actions:

- Physically look at the PSU indicator LEDs.

Output of #ipmitool command


→ Diagram to check each server's power supply

```
ipmitool -H HOSTIP -U ADMIN -P ADMIN -v sel list
```

1		03/13/2014		02:47:10		Power Supply #0xc8		Failure detected		Asserted
2		03/13/2014		03:20:21		Power Supply #0xc8		Failure detected		Deasserted
3		03/13/2014		04:22:22		Power Supply #0xc8		Failure detected		Asserted
4		03/13/2014		05:33:57		Power Supply #0xc8		Failure detected		Deasserted
5		03/13/2014		23:19:20		Power Supply #0xc8		Failure detected		Asserted
6		03/14/2014		02:53:14		Power Supply #0xc8		Failure detected		Deasserted
7		03/18/2014		23:23:35		Power Supply #0xc8		Failure detected		Asserted



Physically check PSU LEDs



Use Prism to check the PSU

Fan diagnostics overview

- The `#ncc hardware_info show_hardware_info` command shows the status of the system fan. (Click [HERE](#) to see the example output.)
- The system fan speed should be set to **Standard Speed** in the system settings.
- Fan speed and status can be checked using `ipmitool`:
 - ESXi `#!/ipmitool sensor list | grep -i FAN`
 - AHV `[root@NTNX-Block-1-A ~]# ipmitool sensor list | grep -i FAN`
 - Hyper-V Powershell `C:\> ipmiutil.exe sensor list | grep -i FAN`

```
[root@HX3500 ~]# ipmitool sensor list | grep -i FAN
Fan 1A Tach      | 4602.000 | RPM | ok | na | 590.000 | na | na | na | na
Fan 1B Tach      | 4410.000 | RPM | ok | na | 630.000 | na | na | na | na
Fan 2A Tach      | 4602.000 | RPM | ok | na | 590.000 | na | na | na | na
Fan 2B Tach      | 4473.000 | RPM | ok | na | 630.000 | na | na | na | na
Fan 3A Tach      | 4602.000 | RPM | ok | na | 590.000 | na | na | na | na
Fan 3B Tach      | 4473.000 | RPM | ok | na | 630.000 | na | na | na | na
Fan 4A Tach      | 4602.000 | RPM | ok | na | 590.000 | na | na | na | na
Fan 4B Tach      | 4410.000 | RPM | ok | na | 630.000 | na | na | na | na
Fan 5A Tach      | 4602.000 | RPM | ok | na | 590.000 | na | na | na | na
Fan 5B Tach      | 4410.000 | RPM | ok | na | 630.000 | na | na | na | na
Fan 6A Tach      | 4602.000 | RPM | ok | na | 590.000 | na | na | na | na
Fan 6B Tach      | 4410.000 | RPM | ok | na | 630.000 | na | na | na | na
Fan Riser1A Tach | 6256.000 | RPM | ok | na | 3332.000 | na | na | na | na
Fan Riser1B Tach | 6324.000 | RPM | ok | na | 3332.000 | na | na | na | na
Fan Riser2A Tach | na       |    | na | na | na       | na | na | na | na
Fan Riser2B Tach | na       |    | na | na | na       | na | na | na | na
```

Note: Users can also check system fan status via IMM/XCC.



Output of #ncc hardware info show hardware info

Scroll down for more information.

FAN

+-----		
Location		Fan 1a tach
Rpm		8988
Status		OK
+-----		
Location		Fan 1b tach
Rpm		10057
Status		OK
+-----		
Location		Fan 2a tach
Rpm		8988
Status		OK
+-----		
Location		Fan 2b tach
Rpm		10057
Status		OK
+-----		
Location		Fan 3a tach
Rpm		8988
Status		OK
+-----		
Location		Fan 3b tach
Rpm		10057
Status		OK



Output of #ncc hardware_info show_hardware_info

Scroll down for more information.

Location	Fan 4a tach
Rpm	8988
Status	OK

Location	Fan 4b tach
Rpm	10057
Status	OK

Location	Fan 5a tach
Rpm	8988
Status	OK

Location	Fan 5b tach
Rpm	10057
Status	OK

Location	Fan 6a tach
Rpm	9660
Status	OK

Location	Fan 6b tach
Rpm	10057
Status	OK

Location	Fan 7a tach
Rpm	9660

Summary

This course enabled you to:

- Describe the procedure used to collect service logs with the Nutanix Prism Web console
- Describe how to manually perform a health check and show hardware information using commands
- Describe the general troubleshooting procedures for ThinkAgile HX Series hardware components